

'J' TYPE

This collet is internally screwed at the top end and is drawn up into position by means of a drawbolt which passes through the centre of the router spindle head. Used on LE range of machines.


METRIC

Part number	Bore d mm
LS 1322	6
LS 1323	8
LS 1324	10
LS 1325	12
LS 1326	14

Box key LS 1511
Drawbolt LS 1466

IMPERIAL

Part number	Bore d inch
LS 800	1/4
LS 801	3/8
LS 802	1/2
LS 803	5/8



'C' TYPE

This collet is held in position by a nut below the head. Used on LS and UX range of routers (except those fitted with the LC router head).


METRIC

Part number	Bore d mm
LSW 3512	6
LSW 3514	8
LSW 3515	9
LSW 3516	10
LSW 3518	12
LSW 3519	13
LSW 3520	14

Collet nut LS 6893 **T**
Spanner LS 191

IMPERIAL

Part number	Bore d inch
LSW 3502	1/4
LSW 3504	3/8
LSW 3506	1/2
LSW 3507	5/8



COLLET BORE MUST MATCH SHANK DIAMETER